

## TUNAP 343

### Radiator cleaner

For quick and easy cleansing of the cooling and heating system. Dissolves and binds residue containing oil and grease. Gets under sludge and corrosion deposits and removes them. Neutralises lime scale residue.



#### Features

- ◊ Cleans the cooling and heating system
- ◊ Dissolves and binds residue containing oil and grease
- ◊ Neutralises lime scale residue
- ◊ Gets under and removes sludge and corrosion deposits

#### Capabilities

- ◊ Improves operating reliability by cleaning the cooling system
- ◊ Safeguards cooling system function
- ◊ Protects new coolant against extant contamination

#### Uses

- ◊ In all radiator repairs to remedy reduced cooling capacity
- ◊ Removes deposits in the cooling system
- ◊ Use when replacing coolant
- ◊ Cleansing after engine repairs (oil in the cooling system)

#### Application

Drain contaminated coolant before cleansing and refill the system with fresh water. Add TUNAP radiator cleaner 43. Run the engine up to operating temperature and let it run for about half an hour. Drain contaminated water / cleaner Repeat the treatment if needed. Then flush the cooling system with clear water. After thorough cleaning refill the cooling system, vent it and check it for leaks. Enough for 10 litres of coolant water.

#### Notes

We recommend replacing all rubber components harmed by oil.

Product designation	Quantity	Article number	VE
Radiator cleaner 43	500 ml	03 343050 AB	12